



Create Openings Rafter+FF




Create openings

- Select single, multiple or all instances of Beam Systems.
- Select the function *Create openings in beam systems* from menu.

NOTE

Openings must be created from linear elements.
Cut of Beam system is done according to openings top face boundary.





Create openings


- If position of opening changes, just repeat the function *Create openings in beam systems* and beam systems will be updated according to a new position of openings.

NOTE

If you want to update beam systems according to openings and also you need to change the beam system end cut or cross-sectional dimensions and update joints and cuts, then select the function *Update Beam Systems (check openings)*.



Selected beam systems
in the slope with three
moved openings



Increase your productivity !



AGA CAD Ltd.
Zalgirio 112A, LT-09300 Vilnius,
Lithuania
Tel. +370 5 2398111
Fax +370 5 2398113
Email info@aga-cad.lt
info@tools4revit.com
www.tools4revit.com