





Select Beam Systems by Roof/Floor Rafter+FF




Select Beam Systems by Roof

- Select any type of a beam system.
- Choose *Select Beam Systems by Roof/Floor* from the menu.





Select Beam Systems by Roof

- Now you can see that all beam systems are selected from the same roof.
- The selected beam systems are the same type.




Select Beam Systems by Floor

- Select a beam system.
- Choose *Select Beam Systems by Roof/Floor* from the menu.



Select Beam Systems by Floor

- Now you can see that all beam systems are selected from the same floor.



Increase your productivity !



AGA CAD Ltd.
Zalgirio 112A, LT-09300 Vilnius,
Lithuania
Tel. +370 5 2398111
Fax +370 5 2398113
Email info@aga-cad.lt
info@tools4revit.com
www.tools4revit.com