






Frame Openings Rafter+FF



Frame Openings (by face)


- Select single, multiple or all instances of Beam Systems.
- Select the function *Frame openings (by face)* from the menu.

Framed openings



Update Joints and Cuts of Framed Openings





- Select single, multiple or all instances of Beam Systems.
- Select the function *Update beam systems* from the menu.



Frame Two Beams

- Select two beams for framing.
- Select *Frame two beams* from the menu.
- Set framing parameters and click *OK*.
- Repeat this step for the other side of opening.

Two beams selected



Increase your productivity !



AGA CAD Ltd.
Zalgirio 112A, LT-09300 Vilnius,
Lithuania
Tel. +370 5 2398111
Fax +370 5 2398113
Email info@aga-cad.lt
info@tools4revit.com
www.tools4revit.com